

# **Experiment No. (5)**


## **Building LAN Network using Hub**

## **Object:**

Build a LAN network using Ethernet cable

### **Theory:**

LAN is a computer network that connects a relatively small area (a single building or group of buildings). Most LANs connect workstations and computers to each other. Each computer (also known as a "node"), has its own processing unit and executes its own programs; however, it can also access data and devices anywhere on the LAN.



#### **Component:**

1. Two or more computers/Laptops. (Example: 5 Computers).



- 2. Two or more NIC (Network Interface Card). In this case 5 NICs for 5 computers.
- 3. LAN cable (UTP cables with the desired length with RJ 45).
- 4. Eight port Hub.

#### **Procedure:**

- Install the NIC into the PCMCIA slot of the PC's mother board.
  NIC is a hardware that interfaces between the computer and the network. The NIC has RJ 45 type port.
- 2. Take the desired length of 5 LAN cables and terminate both the ends with a RJ 45 type connector.
- 3. Now, connect one end of each of 5 cables to the computer and the other end to the Hub.
- 4. Now, The physical network is ready
- 5. Assign IP address, Subnet Mask to every PC.
- 6. To verify the IP address and Subnet Mask assignment in each computer, go to command prompt and type **CD:\>ipconfig /all**
- 7. To check the connectivity between PCs, go to command prompt and type CD:\>ping <destination ip address>
- 8. In return to the ping, the computer receives a reply back as an acknowledgement, thus the LAN connectivity is UP.



## **Discussion:**

- 1. What is the difference between a physical design and a logical design?
- 2. What is the difference between Fast Ethernet and regular Ethernet?
- 3. List the advantages and disadvantages of local area networks.
- 4. What are the primary differences between baseband technology and broadband technology?